

## 42 Mechanic's Ways To Minimize Auto Repairs

This eBook brought to you by:  
[Buy-Ebook.com](http://Buy-Ebook.com)

Our site has got a great collection of the best ebooks which are sold on the Internet, but at a lower price than on any other site.

### Affiliates

Earn 60% Commission On Every Sale! We sell 500+ eBooks.

As a [Buy-Ebook.com](http://Buy-Ebook.com) Associate, we will pay you a Massive 60% referral fee for every sale that you generate. You can [sign up for FREE](#) and start making money straight away.

If you want to directly link to some ebooks related to content of your site, [get affiliate link here](#). Choose any from 500+ titles.

### NOTE:

If you Would like to Offer this Ebook to Your Web Site Visitors as a FREE Download, then please do so. You can post this ebook to your web site, offer it in your newsletter, print it out as a book, give it to your friends, etc. No royalties are necessary. Give it away or offer it as a bonus with your products. You are not allowed to make any changes to it without permission.

The Author, his publishers, agents, resellers or distributors assume no liability or responsibility to any person or entity with respect to any loss or damage or alleged to be caused directly or indirectly by the use of and the advice given in this publication. It is recommended that the users of this publication seek legal, accounting and other independent professional business advice before starting a business or acting upon any advice given. This book is not intended for use as a source of legal, business, accounting or financial advice, but is distribute for information purposes only.

## 42 Mechanic's Ways To Minimize Auto Repairs

While most Americans neglect their automobile, the average U.S. car life is about 10 years (or 100,000 miles). With proper maintenance, you can double and even triple your car's life . This check list tells you what to do.

A. Every two weeks:

1. Check engine oil. Add oil if needed. Use correct viscosity.
2. Check radiator coolant level. Add water or anti-freeze if necessary.
3. Check paint for deep scratches, chips, rust. Repair any damage.

B. Once a month:

4. Check air pressure in all FIVE tires. Add air if required.
5. Check battery fluid (in UNsealed batteries). Add water if necessary.
6. Check fluid in power-steering pump reservoir. Add fluid if needed.

C. Every 3 months or 3,000 miles (whichever comes first):

7. Change entire oil.
8. Change oil filter.
9. Check automatic-transmission fluid level and condition. If necessary add additional fluid.
10. Check all drive belts (fan belts) on engine. Replace any if needed.
11. Adjust drum brakes with manual adjusters.

D. Every 6 months or 6,000 miles:

12. Check carburetor. Replace or make adjustments if necessary.
13. Check pollution-control equipment. Make any adjustments if needed.
14. Replace spark plugs.
15. Check clutch free play. Adjust if required.
16. Check oil in differential and manual transmission. Add oil if needed.
17. Check brake fluid level in master cylinder reservoir. Add brake fluid if necessary.
18. Rotate the tires.
19. Have headlights aimed.
20. Check air condition sight glass (if any). Add refrigerant if required.
21. Lubricate all locks and hinges.
22. Grease all chassis fittings.
23. Wax car body.

E. Every 12 months or 12,000 miles:

24. Inspect brake linings. Replace if necessary.
25. Time for major tune-up. Replace points, plugs, filters, plus adjustments to carburetor, ignition system and pollution-control equipment.
26. Repack wheel bearings.
27. Replace all air filters.
28. Replace all fuel filters.
29. Flush radiator and heater core. Replace antifreeze.
30. Have front-end alignment checked and corrected if needed.
31. Replace windshield wiper blades.
32. Clean crankcase breather cap.
33. Tighten bolts on engine manifolds.
34. Have automatic transmission bands adjusted (if possible).
35. Adjust valve clearance (if required on your car).

F. Every 2 years or 24,000 miles:

36. Replace PCV (positive crankcase ventilating) valve.
37. Bleed brake system and replace brake fluid.
38. Replace automatic transmission fluid and filter.

G. Every 3 years or 30,000 miles:

39. Replace all cooling system and heater hoses.
40. Replace oil in differential and manual transmission.
41. Test ignition cables and replace if needed.

H. Every 50,000 miles:

42. Replace catalytic converter (on cars so equipped).